

Externally steering the Maxicontroller

18-05-21

Preface

There are 2 ways to take control over the Maxicontroller and use the Dimlux Eco system.

The first way is to use 'Direct mode'. When direct mode is used, the Maxicontroller has no control over the steering of the lamps. This is externally done. The sensors which are connected only have a display function. (So NO overheat protection)


The second way is 'RS485 mode. With this mode all settings of the Maxicontroller can be altered and all registers can be read out. Its the same as a user used the keyboard and display of the Maxicontroller. The control will be done by the Maxicontroller. So overheat will still function.

This is for both available models Maxicontrollers. The normal Maxicontroller, and the Maxicontroller Datalog.

RS485 mode


In RS485 mode you can change the settings of the Maxicontroller and readout all its registers.

To make communication possible, you first have to enable 'PC control On' and give it an address to listen to.




```
12:00 20.0 0%
Cont on 23.00 0%
```

Main mode screen




```
Time
1200
```

Press 'SET' key




```
Communications
Mast Off. PC off
```

Press a couple times '+' key




```
Set Masterdata
Off
```

Press 'SET' key




```
Set PC Control
Off
```

Press 'SET' key



```
Set PC Control
On
```

Press '+' key



```
Set PC Control
Address: 1
```

Press '+' key


Wanted PC Control On
Address 1

press 'ESCAPE' key

The display of the Maxicontroller setting PC control onto address 1

Connecting the Maxicontroller for RS485 control


The RS485 connection is made at the ABP port of the Maxicontroller with an RS22 plug.



- Pin 1. -
- Pin 2. RS485 - A
- Pin 2. RS485 - B
- pin 3. GND

Connection to ABP bus

On the other end of the cable an USB to RS485 converter can be used. Preferable an isolated one for a stable connection.



Example of aRS485 connection

RS485 port settings: Baud-rate: 1200 Baud,8 byte, none, parity

ABP protocol

The ABP protocol which is communicated over the RS485 lines consists of a [abp header], master address, slave address, length, command, [data], crc

The ABP header = -127,127,0
Master address = -128
Slave address = address entered into Maxicontroller
length = Length of the data send;
command = command to send
data = data to send
crc = crc

CRC = all data Bit-wise exclusive OR and former value, started from 0x11

example pseudo code:

```
CRC = 11;  
Serial.write((byte) - 128); // send from  
CRC ^= -128;  
Serial.write((byte)1); // send to  
CRC ^= 1;  
Serial.write((byte)1); // command length  
CRC ^= 1;  
Serial.write((byte)52); // command  
CRC ^= 52;  
Serial.write((byte)0); // data...  
CRC ^= 0;  
Serial.write(CRC); // crc
```

Direct mode

It is possible to steer the Maxicontroller with an external voltage. By this way a not 'Dimlux brand' can steer the Dimlux lights.

The Maxi-controller will NOT 'dim' or 'shutdown' the lights when the temperature is to hot. This has to be done by the device steering the Maxi-controller

Setting the Maxicontroller in to the 'direct mode'

You have to set the 'Light control' to 'the direct mode' This can be done by pressing the 'off/modus' key a couple of times. When the setting 'as Direct' is in screen accept it with the 'set' key.

	Main mode screen
Press 'OFF/MODUS' key	
	
Press 'OFF/MODUS' key	
	
Press 'OFF/MODUS' key	
	
Press 'OFF/MODUS' key	
	
Press 'OFF/MODUS' key	
	
Press 'OFF/MODUS' key	
	Wanted light control



The display of the Maxicontroller setting Direct mode

Connecting the Maxicontroller for direct control

The steer voltage has to be sourced onto the infrared port.



RJ45 Pinout T-568B



- | | |
|-----------------|----------------|
| 1. White Orange | 5. White Blue |
| 2. Orange | 6. Green |
| 3. White Green | 7. White Brown |
| 4. Blue | 8. Brown |

- Pin 1. -
- Pin 2. -
- Pin 3. voltage for channel A
- Pin 4. -
- Pin 5. -
- Pin 6. voltage for channel B
- pin 7. GND
- pin 8. GND

The is a RJ45 plug

Steering voltage

The input-voltage may not exceed 13 volt. The load of the Maxicontroller is max. 1mA

Power percentage out, is linear with voltage in. The ballast stay OFF, below 3000 mV
See table.

Note: Below 5000 mV (= 50%) steering is off. This is done because HPS (or CMH) lamps can't ignite below 50% of its power.

Voltage in (mV)	Percentage steering (%)
0	0
1000	0
2000	0
2500	0
3000	0
3500	0
4000	0
4500	0
5000	50
5500	55
6000	60
6500	65
7000	70
7500	75
8000	80
8500	85
9000	90
9500	95
10000	100
10500	105
11000	110
11500	115
12000	120
>12000	120

Steering voltage in, power percentage out